

## GPS Installation Instructions

- Turn on GPS
- Go to 'Today' click on "connections" button at bottom
- Turn on BlueTooth
- Click on 'Settings' > 'Bluetooth Settings'
- Click on 'Devices' tab
- Click on 'New Partnership'
- Find HI-406 in list, select it. Click next
- Passphrase 0000 (4 zeros)
- Select 'Serial Port'
- Done!



## GPS Synchronization Instructions

- Click on 'COM Ports'
- New Outgoing Port
- Click on the HI-406
- Select COM0 (zero)
- Uncheck Secure
- Click OK
- Start SWRemote
- Log into the system
- GPS unit will connect. Done!



• BT / GPS LED Indicator  
• Female USB outlet for PDA charging (DC 5V out)

### LED Indicator (Red)

LED off	Receiver switch off
LED flashing	GPS Position Fixed
LED stay on	GPS Signal searching

### LED Indicator (Blue)

LED off	Bluetooth® switch off
LED flashing	Bluetooth® searching
LED stay on	Bluetooth® connected

**Please note:** The phone and the GPS unit will not "connect" until you've logged into SWRemote